

# Torx Screw Head Types

Screw Size	Thread Diameter	TORX SCREW HEAD TYPES								Opening Depth (D) Set Screw
		Internal Torx Hex Washer	Pan	Flat	Hex	Truss	Fillister	Oval	Socket Head Cap Screw	
2	.086	<b>T7</b>	<b>T7</b>	<b>T6</b>	–	–	–	–	–	<b>T3</b>
3	.099	<b>T8</b>	<b>T8</b>	<b>T7</b>	–	–	–	–	–	<b>T5</b>
4	.112	<b>T9</b>	<b>T9</b>	<b>T8</b>	<b>T9</b>	–	<b>T9</b>	–	<b>T10</b>	<b>T6</b>
5	.125	<b>T10</b>	<b>T10</b>	<b>T9</b>	<b>T10</b>	–	<b>T10</b>	<b>T10</b>	<b>T10</b>	<b>T7</b>
6	.138	<b>T15</b>	<b>T15</b>	<b>T10</b>	<b>T15</b>	<b>T10</b>	<b>T15</b>	<b>T15</b>	<b>T15</b>	<b>T7</b>
8	.164	<b>T20</b>	<b>T20</b>	<b>T15</b>	<b>T20</b>	<b>T15</b>	<b>T20</b>	<b>T20</b>	<b>T25</b>	<b>T8</b>
10	.190	<b>T25</b>	<b>T25</b>	<b>T20</b>	<b>T25</b>	<b>T20</b>	<b>T25</b>	<b>T25</b>	<b>T27</b>	<b>T10</b>
12	.216	<b>T27</b>	<b>T27</b>	<b>T25</b>	<b>T27</b>	<b>T25</b>	<b>T27</b>	<b>T27</b>	<b>T27</b>	<b>T10</b>
1/4	.250	<b>T30</b>	<b>T30</b>	<b>T27</b>	<b>T30</b>	<b>T27</b>	<b>T30</b>	<b>T30</b>	<b>T30</b>	<b>T20</b>
5/16	.312	–	–	<b>T40</b>	<b>T40</b>	<b>T40</b>	<b>T40</b>	<b>T40</b>	<b>T45</b>	<b>T27</b>
3/8	.375	–	<b>T45</b>	<b>T40</b>	<b>T45</b>	<b>T45</b>	<b>T45</b>	<b>T45</b>	<b>T50</b>	<b>T30</b>
7/16	.437	–	<b>T50</b>	<b>T50</b>	–	<b>T45</b>	<b>T50</b>	<b>T50</b>	<b>T55</b>	<b>T40</b>
1/2	.500	–	<b>T55</b>	<b>T50</b>	–	<b>T50</b>	<b>T55</b>	<b>T50</b>	<b>T55</b>	<b>T45</b>