



# Bit Part Number Index

Lance #	Pg	Lance #	Pg	Lance #	Pg	Lance #	Pg	Lance #	Pg
250SS1	95	MBH1/4-3	103	P3-2-ACR	93	T20	99	T-30-6	101
250SS2	95	MBH1/4-4	103	PZ0	102	T25	99	T-40-6	101
250SS3	95	MBH1/4-6	103	PZ1	102	T27	99	TT5	101
250SS4	95	MBH1/4-10	103	PZ2	102	T30	99	TT6	101
250SS5	95	MBH1/4-12	103	PZ3	102	T40	99	TT7	101
250SS6	95	MBHC 1/4	103	PZ1-2	102	T5-2	100	TT8	101
250SS8	95	MBHL 1/4	103	PZ2-2	102	T6-2	100	TT9	101
250SS10	95	MBHR 1/4	103	PZ3-2	102	T7-2	100	TT10	101
250SS12	95	MBHR 1/4-4	103	SL1-2	95	T8-2	100	TT15	101
5P1	93	MBHR 1/4-6	103	SL2-2	95	T9-2	100	TT20	101
5P2	93	MBHR 1/4-8	103	SL3-2	95	T10-2	100	TT25	101
5P3	93	MBHR 1/4-10	103	SL4-2	95	T15-2	100	TT27	101
5P4	93	MBHS 1/4	103	SL5-2	95	T20-2	100	TT30	101
5PZ1	102	MBHT 1/4	103	SL6-2	95	T25-2	100	TT40	101
5PZ2	102	MBHW 1/4	103	SL8-2	95	T27-2	100	TP2	93
5PZ3	102	MBHY 1/4	103	SL10-2	95	T30-2	100	TP3	93
5PZ4	102	MBHZ 1/4	103	SL12-2	95	T40-2	100	TW1	102
5T30	99	PO	92	SL1-3	95	T5-3	100	TW2	102
5T40	99	P1	92	SL2-3	95	T6-3	100	TW3	102
5T45	99	P2	92	SL4-3	95	T7-3	100	TW4	102
5T50	99	P3	92	SL5-3	95	T8-3	100	TW5	102
5T55	99	P4	92	SL6-3	95	T9-3	100	TW6	102
5T60	99	P1-FX	92	SL8-3	95	T10-3	100	TW7	102
5TT40	101	P2-FX	92	SL10-3	95	T15-3	100	TW8	102
5TT45	101	PR1	92	SL1-4	95	T20-3	100		
5TT50	101	PR2	92	SL2-4	95	T25-3	100		
5TT55	101	P2-15	92	SL3-4	95	T27-3	100		
56SS4	96	P1-20	92	SL4-4	95	T30-3	100		
56SS6	96	P2-20	92	SL5-4	95	T40-3	100		
56SS8	96	P3-20	92	SL6-4	95	T6-4	100		
56SS10	96	PO-2	92	SL8-4	95	T7-4	100		
56SS12	96	P1-20	92	SL10-4	95	T8-4	100		
56SS14	96	P2-20	92	SL1-6	96	T9-4	100		
56SS16	96	P3-20	92	SL2-6	96	T10-4	100		
BF4	97	P1-3	92	SL3-6	96	T15-4	100		
BF5	97	P2-3	92	SL4-6	96	T20-4	100		
BF6	97	P3-3	92	SL5-6	96	T-25-4	100		
BF8	97	P1-4	92	SL6-6	96	T27-4	100		
BF10	97	P2-4	92	SL8-6	96	T30-4	100		
BF12	97	P3-4	92	SL10-6	96	T40-4	100		
BF14	97	P1-6	92	T3	99	T6-6	100		
BFP6	97	P2-6	92	T4	99	T7-6	100		
BFP8	97	P3-6	92	T5	99	T8-6	100		
BFP10	97	P1-ACR	93	T6	99	T9-6	100		
BFP12	97	P2-ACR	93	T7	99	T10-6	100		
BFP14	97	P3-ACR	93	T8	99	T15-6	100		
BFP16	97	PR2-ACR	93	T9	99	T20-6	101		
BFP20	97	P1-2-ACR	93	T10	99	T25-6	101		
BFP22	97	P2-2-ACR	93	T15	99	T27-6	101		

PHONE (248) 549-1968 FAX (248) 549-1960